

FIG. 1




FIG. 2A




FIG. 2B




FIG. 3




FIG. 4A




FIG. 4B





FIG. 5



Purpose:
To maintain position of floatation device on inserted cable. (This technique is used to control depth of underwater speaker.

FIG. 6

Normal, Play All, Load and Save Procedures




FIG. 7

Select Sequence & Selecting One Sound Procedures

